



3 Marsh Green Road North,
Marsh Barton,
Exeter,
Devon,
EX2 8NY

M - Way Roof Bar Application List
UNIVERSAL ROOF BARS

MAKE	MODEL	N° OF DOORS	YEAR	For vehicles with factory fitted roof rails			
				EAGLE RB1040	XL EAGLE RB1045	M-PROFILE RB1030	M-PROFILE RB1035
ALFA ROMEO	156 Crosswagon	5	04>07	X			
ALFA ROMEO	156 Sportwagon	5	00>05	X			
ALFA ROMEO	159 Sportwagon	5	06>13	X			
AUDI	A3 Sportback (8PA)	5	04>12				X
AUDI	A3 Sportback (8VA)		16>				X
AUDI	A4 Avant	5	94>00	X			
AUDI	A4 Avant	5	00>08	X			
AUDI	A4 Avant (8K)	5	08>14				X
AUDI	A4 Avant (8K)	5	15>				X
AUDI	A4 Allroad	5	09>16		X		
AUDI	A4 Allroad	5	16>		X		X
AUDI	A6 Avant	5	94>97	X			
AUDI	A6 Avant	5	98>04	X			
AUDI	A6 Avant (4F)	5	04>11				X
AUDI	A6 Avant (4G)	5	11>15				X
AUDI	A6 Avant (4G)	5	15>				X
AUDI	A6 Allroad	5	99>05	X			
AUDI	A6 Allroad	5	06>11		X		
AUDI	A6 Allroad (4G)	5	12>14				X
AUDI	A6 Allroad (4G)	5	14>				X
AUDI	Q3 (8U)	5	11>				X
AUDI	Q5 (8R)	5	08>14				X
AUDI	Q5 (8R)	5	14>16				X
AUDI	Q5 (FY)	5	17>				X
AUDI	Q7 (4L)	5	05>09				X
BMW	2 Series Active Tourer (F45)	5	14>				X
BMW	2 Series Gran Tourer (F46)		15>				X
BMW	3 Series Touring (E36)	5	94>99	X			
BMW	3 Series Touring (E46/3)	5	99>05	X			
BMW	3 Series Touring (E91)	5	05>12	X			
BMW	3 Series Touring (F31)	5	12>15			X	
BMW	3 Series Touring (F31)	5	15>				X
BMW	5 Series Touring (E39)	5	95>04	X			
BMW	5 Series Touring (E61)	5	03>10	X			
BMW	5 Series Touring (F11)	5	10>13				X
BMW	5 Series Touring (F11)	5	13>				X
BMW	X1 (E84)	5	09>12				X
BMW	X1 (E84)	5	12>15				X
BMW	X1 (F48)		15>				X
BMW	X3 (E83)	5	04>10		X		
BMW	X3 (F25)	5	10>14				X
BMW	X3 (F25)		14>				X

Whilst every effort is made to ensure information is correct, Western Towing will not be held responsible for errors. Always check your vehicle handbook for guidance before fitting a roof bar

MAKE	MODEL	N° OF DOORS	YEAR	For vehicles with factory fitted roof rails			
				EAGLE RB1040	XL EAGLE RB1045	M-PROFILE RB1030	M-PROFILE RB1035
BMW	X4 (F26)	5	14>				X
BMW	X5 (E53)	5	99>06		X		
BMW	X5 (E70)	5	06>10		X		
BMW	X5 (E70)	5	10>13				X
BMW	X5 (F15)	5	13>15				X
BMW	X5 (F15)	5	15>				X
CADILLAC	BLS		06>10	X			
CADILLAC	SRX		05>09	X			
CHEVROLET	Aveo (T300)	5	11>				
CHEVROLET	Blazer		95>05		X		
CHEVROLET	Captiva	5	06>11	X			
CHEVROLET	Captiva	5	11>	X			
CHEVROLET	Corsa		93>10	X			
CHEVROLET	Cruze Station Wagon	5	01>04	X			
CHEVROLET	Cruze Station Wagon	5	11>	X			
CHEVROLET	HHR	5	06>11	X			
CHEVROLET	Lacetti	5	02>09	X			
CHEVROLET	Lacetti	5	09>11	X			
CHEVROLET	Matiz	5	05>09	X			
CHEVROLET	Nubira II Station Wagon	5	05>	X			
CHEVROLET	Nubria III		04>07	X			
CHEVROLET	Rezzo		00>08	X			
CHEVROLET	Spark		10>	X			
CHEVROLET	Spin		12>	X			
CHEVROLET	Tahoe	5	95>	X			
CHEVROLET	Tavera		05>		X		
CHEVROLET	Tracker		06>	X			
CHEVROLET	Trans Sport	5	97>99		X		
CHEVROLET	Uplander		05>09	X			
CHEVROLET	Zafira		01>12	X			
CHRYSLER	300 C Touring	5	05>11		X		
CHRYSLER	Aspen		07>09	X			
CHRYSLER	Town & Country		95>05	X			
CHRYSLER	Voyager	5	96>00		X		
CHRYSLER	Grand Voyager	5	96>00		X		
CITROEN	Berlingo (Mk1)	5	96>10		X		
CITROEN	C3 Picasso	5	08>15		X		
CITROEN	C3 Xtr		07>09	X			
CITROEN	C4 Aircross	5	12>				X
CITROEN	C4 Picasso (Mk1)	5	06>13		X		
CITROEN	C5 (Mk1) Tourer		01>05	X			
CITROEN	C5 (Mk1) Tourer		05>08	X			
CITROEN	C5 Tourer	5	08>12	X			
CITROEN	C5 (Mk2) Tourer		13>	X			
CITROEN	C5 Cross Tourer	5	10>		X		
CITROEN	C-Crosser	5	07>12		X		
CITROEN	Grand C4 Picasso	5	06>13		X		
CITROEN	XM Break	5	94>00	X			

Whilst every effort is made to ensure information is correct, Western Towing will not be held responsible for errors. Always check your vehicle handbook for guidance before fitting a roof bar

MAKE	MODEL	N° OF DOORS	YEAR	For vehicles with factory fitted roof rails			
				EAGLE RB1040	XL EAGLE RB1045	M-PROFILE RB1030	M-PROFILE RB1035
CITROEN	ZX Break	5	94>99	X			
DACIA	Dokker		12>	X			
DACIA	Duster	5	08>13	X			
DACIA	Lodgy	5	12>				X
DACIA	Logan MCV		04>13	X			
DACIA	Logan MCV		13>	X			
DACIA	Sandero Stepway	5	09>12	X			
DACIA	Sandero Stepway	5	13>	X			
DAEWOO	Matiz	5	98>07	X			
DAEWOO	Nubira Station Wagon	5	97>03	X			
DAEWOO	Rezzo		00>08	X			
DAEWOO	Tacuma	5	00>04	X			
DAIHATSU	Feroza	5	87>98	X			
DAIHATSU	Terios		06>		X		
DAIHATSU	Xenia		11>		X		
DODGE	Caravan		96>05	X			
DR	Citycross	5	13>	X			
DR	Dr2	5	10>	X			
DR	Dr5	5	08>13	X			
DR	Dr5	5	13>		X		
FIAT	500 X	5	15>				X
FIAT	Croma	5	05>07	X			
FIAT	Croma	5	07>10	X			
FIAT	Doblò	5	00>10		X		
FIAT	Doblò Malibù	5	00>05		X		
FIAT	Fiorino III		07>		X		
FIAT	Freemont	5	11>		X		
FIAT	Freemont Cross		14>		X		
FIAT	Idea	5	05>12	X			
FIAT	Marea Weekend	5	96>03	X			
FIAT	Marengo	5	97>01	X			
FIAT	Palio Weekend	5	97>01	X			
FIAT	Panda Cross		04>14		X		
FIAT	Panda III Cross		14>		X		
FIAT	Panda III Aircross		14>		X		
FIAT	Panda	3	80>03		X		
FIAT	Panda II	5	03>12		X		
FIAT	Qubo	5	08>16		X		
FIAT	Qubo	5	16>		X		
FIAT	Sedici	5	05>14	X			
FIAT	Stilo Station Wagon	5	01>10		X		
FIAT	Strada		04>	X			
FORD	Aerostar		86>97	X			
FORD	B-Max	5	12>			X	
FORD	C-Max II	5	10>		X		
FORD	C-Max 7 II	5	10>		X		
FORD	Edge		06>10		X		
FORD	Edge	5	16>		X		

Whilst every effort is made to ensure information is correct, Western Towing will not be held responsible for errors. Always check your vehicle handbook for guidance before fitting a roof bar

MAKE	MODEL	N° OF DOORS	YEAR	For vehicles with factory fitted roof rails			
				EAGLE RB1040	XL EAGLE RB1045	M-PROFILE RB1030	M-PROFILE RB1035
FORD	Escape		08>12		X		
FORD	Escape II		12>		X		
FORD	Escort Estate	5	90>00	X			
FORD	Everest		03>15	X			
FORD	Everest		15>	X			
FORD	Explorer III		02>05	X			
FORD	Explorer IV		06>10	X			
FORD	Explorer V		11>	X			
FORD	Focus I Estate	5	98>04	X			
FORD	Focus II Estate	5	04>11	X			
FORD	Focus III Estate	5	11>14				X
FORD	Focus III Estate	5	14>				X
FORD	Galaxy	5	95>00		X		
FORD	Galaxy	5	00>05		X		
FORD	Galaxy	5	06>10		X		
FORD	Galaxy II	5	11>15				X
FORD	Galaxy III	5	15>				X
FORD	Grand C-Max		10>		X		
FORD	Kuga	5	08>12		X		
FORD	Kuga II	5	12>		X		
FORD	Maverick	5	93>99	X			
FORD	Mondeo Estate	5	93>00	X			
FORD	Mondeo Estate	5	01>06	X			
FORD	Mondeo III Estate	5	07>10	X			
FORD	Mondeo III Estate	5	10>14				X
FORD	Mondeo IV Estate	5	14>				X
FORD	Ranger		11>		X		
FORD	Scorpio Estate	5	94>99	X			
FORD	Tourneo Connect		13>				X
FORD	Tourneo Courier		13>		X		
FORD	Transit Courier		14>		X		
HONDA	Accord Tourer	5	03>07	X			
HONDA	Accord Tourer		08>	X			
HONDA	Civic IX Tourer	5	13>15				X
HONDA	Cr-V		96>02	X			
HONDA	Elysion		04>		X		
HONDA	Odissey		03>08		X		
HONDA	Odissey		10>		X		
HONDA	Pilot I		03>08		X		
HONDA	Pilot II		09>15		X		
HONDA	Pilot III		15>		X		
HONDA	Shuttle		10>		X		
HYUNDAI	Atos	5	97>08	X			
HYUNDAI	Avante		96>	X			
HYUNDAI	Elantra (J2) Station Wagon		95>00	X			
HYUNDAI	Entourage II (VQ)		06>14		X		
HYUNDAI	Getz Cross	5	06>11	X			
HYUNDAI	HB20		12>	X			

Whilst every effort is made to ensure information is correct, Western Towing will not be held responsible for errors. Always check your vehicle handbook for guidance before fitting a roof bar

MAKE	MODEL	N° OF DOORS	YEAR	For vehicles with factory fitted roof rails			
				EAGLE RB1040	XL EAGLE RB1045	M-PROFILE RB1030	M-PROFILE RB1035
HYUNDAI	i10 (IA)	5	13>	X			
HYUNDAI	i20 Active		15>	X			
HYUNDAI	i30 Tourer	5	07>10	X			
HYUNDAI	ix35	5	10>13				X
HYUNDAI	ix35 (standard rail)		10>	X			
HYUNDAI	ix35	5	13>				X
HYUNDAI	Lantra Station Wagon	5	95>00	X			
HYUNDAI	Matrix	5	01>08	X			
HYUNDAI	Maxcruz (DM)		12>				X
HYUNDAI	Santa Fe (SM)	5	00>06	X			
HYUNDAI	Santa Fe (CM)	5	06>12		X		
HYUNDAI	Santa Fe (DM)	5	12>				X
HYUNDAI	Starex		97>07	X			
HYUNDAI	Terracan	5	02>06	X			
HYUNDAI	Trajet	5	99>08	X			
HYUNDAI	Tucson	5	04>09	X			
HYUNDAI	Tucson (TL)	5	15>				X
INFINITY	Ex	5	07>13		X		
INFINITY	Fx	5	08>13		X		
INFINITY	Q30	5	16>			X	
INFINITY	Qx50		13>	X			
INFINITY	Qx70		13>	X			
JAGUAR	F-Pace		16>				X
JAGUAR	XF Sportbrake	5	12>				X
JAGUAR	X-Type Estate	5	03>	X			
JEEP	Cherokee (KJ)	5	01>04	X			
JEEP	Cherokee (KJ)	5	05>07		X		
JEEP	Cherokee (KK)		08>13		X		
JEEP	Cherokee (KL)	5	14>		X		
JEEP	Grand Cherokee	5	99>04	X			
JEEP	Grand Cherokee	5	05>10		X		
JEEP	Patriot	5	07>12	X			
JEEP	Renegade	5	14>		X		
KATAI	Gonow	5	06>		X		
KIA	Carens (RS)	5	99>02	X			
KIA	Carens (UN)	5	02>06	X			
KIA	Carens (RP)	5	13>				X
KIA	Carnival (GQ)	5	98>01	X			
KIA	Carnival (GQ)	5	01>05	X			
KIA	Carnival (VQ)	5	06>11	X			
KIA	Cee'D Sports Wagon (EU)	5	12>				X
KIA	Cee'D Station Wagon	5	06>12	X			
KIA	Grand Carnival	5	06>11	X			
KIA	Niro		16>				X
KIA	Optima (JF)	4	16>				X
KIA	Rio Hatchback (DC)		00>05	X			
KIA	Sedona	5	06>11		X		
KIA	Sorento (BL)	5	02>09		X		

Whilst every effort is made to ensure information is correct, Western Towing will not be held responsible for errors. Always check your vehicle handbook for guidance before fitting a roof bar

MAKE	MODEL	N° OF DOORS	YEAR	For vehicles with factory fitted roof rails			
				EAGLE RB1040	XL EAGLE RB1045	M-PROFILE RB1030	M-PROFILE RB1035
KIA	Sorento (XM)	5	09>14		X		
KIA	Sorento (UM)	5	14>				X
KIA	Soul	5	08>14		X		
KIA	Soul (PS)	5	14>				X
KIA	Sportage (JA)	5	94>02	X			
KIA	Sportage (JE)	5	04>10	X			
KIA	Sportage (SL)	5	10>13				X
KIA	Sportage (SL)	5	14>16				X
KIA	Sportage (QL)	5	16>				X
LAND ROVER	Discovery I		89>98		X		
LAND ROVER	Discovery II		98>04		X		
LAND ROVER	Discovery Sport	5	15>		X		
LAND ROVER	Freelander		99>06	X			
LAND ROVER	Freelander MK2		07>	X			
LAND ROVER	Range Rover II		94>02		X		
LEXUS	GX		02>09		X		
LEXUS	NX Hybrid	5	14>				X
LEXUS	RX (XU30)	5	03>09	X			
LEXUS	RX (AL10) Hybrid	5	09>11	X			
LEXUS	RX (AL20) Hybrid	5	15>				X
MAZDA	5	5	05>13	X			
MAZDA	6 Atenza (GG) Estate	5	02>08	X			
MAZDA	6 Atenza (GH) Estate	5	08>13		X		
MAZDA	6 Atenza (GJ) Estate		13>		X		
MAZDA	626 Estate	5	88>02	X			
MAZDA	Atenza		02>	X			
MAZDA	Demio	5	96>02	X			
MAZDA	MPV	5	97>98	X			
MAZDA	Navajo		00>11		X		
MAZDA	Premacy	5	05>13	X			
MAZDA	Tribute		01>12		X		
MERCEDES	C Class Estate (S202)	5	93>00	X			
MERCEDES	C Class Estate (S203)	5	00>07	X			
MERCEDES	C Class Estate (S204)	5	07>14	X			
MERCEDES	C Class Estate (S205)	5	14>			X	
MERCEDES	GLC (X253)		15>				X
MERCEDES	E Class Estate (S210)	5	95>02	X			
MERCEDES	E Class Estate (S211)	5	03>08	X			
MERCEDES	E Class Estate (S212)	5	09>13		X		
MERCEDES	E Class Estate (S213)		16>				X
MERCEDES	GL (X164)	5	06>12		X		
MERCEDES	GL (X166)		12>		X		
MERCEDES	GLA (X156)	5	14>				X
MERCEDES	GLE		15>		X		
MERCEDES	GLK (X204)		12>		X		
MERCEDES	GLK (X204)	5	08>12		X		
MERCEDES	M Class (W163)	5	97>05		X		
MERCEDES	M Class (W164)	5	05>11		X		

Whilst every effort is made to ensure information is correct, Western Towing will not be held responsible for errors. Always check your vehicle handbook for guidance before fitting a roof bar

MAKE	MODEL	N° OF DOORS	YEAR	For vehicles with factory fitted roof rails			
				EAGLE RB1040	XL EAGLE RB1045	M-PROFILE RB1030	M-PROFILE RB1035
MERCEDES	M Class (W166)	5	11>		X		
MERCEDES	Vaneo (W414)		02>05		X		
MG	ZT-T Station Wagon	5	01>05	X			
MINI	Countryman		16>	X			
MITSUBISHI	ASX	5	10>13				X
MITSUBISHI	ASX	5	13>				X
MITSUBISHI	Galant		96>03	X			
MITSUBISHI	Grandis	5	03>11	X			
MITSUBISHI	Montero (V60)		99>06		X		
MITSUBISHI	Nativa		15>	X			
MITSUBISHI	Nativa (V60)		99>06		X		
MITSUBISHI	Outlander	5	07>12		X		
MITSUBISHI	Outlander	5	12>				X
MITSUBISHI	Outlander PHEV	5	14>				X
MITSUBISHI	Pajero (V60)		99>06		X		
MITSUBISHI	Pajero Full		06>		X		
MITSUBISHI	Shogun (V20)		91>99		X		
MITSUBISHI	Shogun (V60)		99>06		X		
MITSUBISHI	Space Runner	5	91>02	X			
MITSUBISHI	Space Star	5	98>05	X			
MITSUBISHI	Space Wagon	5	91>03	X			
MITSUBISHI	Space Wagon		04>	X			
NISSAN	Almera Tino	5	00>06	X			
NISSAN	Grand Livina		13>		X		
NISSAN	Lafesta		04>		X		
NISSAN	Livina X-Gear		13>		X		
NISSAN	Murano	5	02>07		X		
NISSAN	Murano		08>		X		
NISSAN	Navara (D23)	5	14>		X		
NISSAN	Pathfinder (R52)		12>		X		
NISSAN	Patrol (Y62)		10>		X		
NISSAN	Primera (W12)		91>07	X			
NISSAN	Primera Break	5	90>02	X			
NISSAN	Qashqai (J10)	5	06>14		X		
NISSAN	Qashqai (J11)	5	14>		X		
NISSAN	Qashqai+2	5	08>13		X		
NISSAN	Terrano 2	5	95>05		X		
NISSAN	Xterra		04>15	X			
NISSAN	X-Trail (T32)	5	13>		X		
PEUGEOT	206 Station Wagon		02>	X			
PEUGEOT	207 Station Wagon		07>09	X			
PEUGEOT	207 Station Wagon		10>14	X			
PEUGEOT	306 Break Station Wagon		93>02	X			
PEUGEOT	307 Station Wagon	5	02>08	X			
PEUGEOT	308 Station Wagon	5	08>13		X		
PEUGEOT	308 Station Wagon	5	14>				X
PEUGEOT	406 Station Wagon	5	97>05	X			
PEUGEOT	407 Station Wagon	5	04>12		X		

Whilst every effort is made to ensure information is correct, Western Towing will not be held responsible for errors. Always check your vehicle handbook for guidance before fitting a roof bar

MAKE	MODEL	N° OF DOORS	YEAR	For vehicles with factory fitted roof rails			
				EAGLE RB1040	XL EAGLE RB1045	M-PROFILE RB1030	M-PROFILE RB1035
PEUGEOT	1007	3	05>10		X		
PEUGEOT	2008	5	13>	X			
PEUGEOT	3008	5	09>16				X
PEUGEOT	4007	5	07>12		X		
PEUGEOT	4008	5	10>13				X
PEUGEOT	4008		13>				X
PEUGEOT	Bipper Tepee		08>		X		
PEUGEOT	Partner Air		01>		X		
PEUGEOT	Partner Tepee	5	08>15		X		
PEUGEOT	Ranch	5	01>	X			
PONTIAC	Transport	5	97>		X		
PORSCHE	Cayenne	5	10>		X		X
RENAULT	Clio III Sportour	5	07>12	X			
RENAULT	Clio IV Sportour	5	13>16	X			
RENAULT	Clio IV Sportour		16>	X			X
RENAULT	Espace IV		02>15		X		
RENAULT	Espace V		15>		X		
RENAULT	Express		92>97		X		
RENAULT	Grand Scenic IV		17>				X
RENAULT	Kadjar		15>				X
RENAULT	Kangoo Express (Mk1)	5	98>08	X			
RENAULT	Kangoo Express (Mk2)	5	08>		X		
RENAULT	Koleos	5	08>10		X		
RENAULT	Koleos	5	11>14		X		
RENAULT	Koleos	5	14>		X		
RENAULT	Laguna I Tourer	5	96>01	X			
RENAULT	Laguna II Grand Tourer	5	00>08	X			
RENAULT	Laguna III Sport Tourer	5	08>	X			
RENAULT	Megane II Tourer	5	02>10	X			
RENAULT	Megane III Sport Tourer		09>16	X			
RENAULT	Megane IV Sporter		16>				X
RENAULT	Scenic III (Without Glass Roof)	5	13>16		X		
RENAULT	Scenic X Mod	5	13>		X		
RENAULT	Scenic X Mode Cross		13>		X		
RENAULT	Talisman Sporter		16>				X
ROVER	75 Tourer	5	00>05	X			
ROVER	Streetwise		04>05	X			
SAAB	9-3 Sport Hatch	5	02>08	X			
SAAB	9-3 Sport Hatch	5	08>13	X			
SAAB	9-3 X	5	09>13	X			
SAAB	9-4 X	5	10>11	X			
SAAB	9-5 Station Wagon	5	99>06		X		
SAAB	9-5 Station Wagon	5	06>12		X		
SAAB	9-7 X	5	06>		X		
SEAT	Alhambra	5	96>10		X		
SEAT	Alhambra	5	15>		X		
SEAT	Altea XL	5	09>			X	
SEAT	Ateca		16>	X			
SEAT	Exeo Sport Tech		09>13	X			

Whilst every effort is made to ensure information is correct, Western Towing will not be held responsible for errors. Always check your vehicle handbook for guidance before fitting a roof bar

MAKE	MODEL	N° OF DOORS	YEAR	For vehicles with factory fitted roof rails			
				EAGLE RB1040	XL EAGLE RB1045	M-PROFILE RB1030	M-PROFILE RB1035
SEAT	Ibiza IV ST	5	10>			X	
SEAT	Leon III	5	12>			X	
SEAT	Leon III X-Perience ST		15>			X	
SHUANGHUAN	Ceo	5	06>08		X		
SKODA	Fabia Estate	5	99>07	X			
SKODA	Fabia Estate	5	07>14	X			
SKODA	Fabia Estate		15>	X			
SKODA	Fabia Scout		09>14	X			
SKODA	Felicia Estate	5	94>01	X			
SKODA	Kodiaq		17>	X			
SKODA	Octavia II Estate	5	04>12	X			
SKODA	Octavia III Estate	5	13>16	X			
SKODA	Octavia III Estate		17>	X			
SKODA	Octavia Scout		07>	X			
SKODA	Praktik		06>	X			
SKODA	Roomster	5	06>	X			
SKODA	Superb Estate	5	10>13	X			
SKODA	Superb Estate	5	13>15		X		
SKODA	Yeti	5	09>13		X		
SKODA	Yeti	5	13>		X		
SKODA	Yeti Outdoor	5	13>		X		
SSANGYONG	Korando	5	10>		X		
SSANGYONG	Kyron	5	05>		X		
SSANGYONG	Rexton	5	01>06	X			
SSANGYONG	Rexton	5	06>12	X			
SSANGYONG	Rexton	5	13>		X		
SSANGYONG	Rodius	5	04>13		X		
SSANGYONG	Tivoli	5	15>				X
SSANGYONG	XLV		16>	X			
SUBARU	Forester (SH)	5	08>12		X		
SUBARU	Forester (SJ)	5	13>		X		
SUBARU	Impreza Estate	5	93>07	X			
SUBARU	Justy		07>	X			
SUBARU	Legacy Estate	5	09>	X			
SUBARU	XV	5	12>	X			
SUBARU	Tribeca	5	06>		X		
SUZUKI	Baleno	5	95>02	X			
SUZUKI	Gran Vitara		98>05	X			
SUZUKI	Ignis	5	00>08	X			
SUZUKI	Ignis		16>	X			
SUZUKI	Jimny	3	98>12	X			
SUZUKI	Karimun		97>05		X		
SUZUKI	S-Cross		16>			X	
SUZUKI	Sx4	5	06>	X			
SUZUKI	Sx4 S-Cross		13>16			X	
SUZUKI	Vitara		88>98	X			
SUZUKI	Vitara		15>			X	
SUZUKI	Wagon R+		97>05		X		

Whilst every effort is made to ensure information is correct, Western Towing will not be held responsible for errors. Always check your vehicle handbook for guidance before fitting a roof bar

MAKE	MODEL	N° OF DOORS	YEAR	For vehicles with factory fitted roof rails			
				EAGLE RB1040	XL EAGLE RB1045	M-PROFILE RB1030	M-PROFILE RB1035
SUZUKI	XL-7		98>10	X			
TATA	Indigo I Estate	5	07>09	X			
TATA	Indigo II Estate		09>	X			
TATA	Xenon		07>	X			
TOYOTA	Auris Touring Sports (E180)	5	13>15			X	
TOYOTA	Auris Touring Sports (E180)	5	15>			X	
TOYOTA	Avanza		11>		X		
TOYOTA	Avensis Verso (T210)		97>00	X			
TOYOTA	Avensis Verso (T210)		00>03	X			
TOYOTA	Avensis Verso (T250)		03>06	X			
TOYOTA	Avensis Verso (T250)		06>09	X			
TOYOTA	Avensis Estate (T210)		97>00	X			
TOYOTA	Avensis Estate (T210)		00>03	X			
TOYOTA	Avensis Estate (T250)		03>06	X			
TOYOTA	Avensis Estate (T250)		06>09	X			
TOYOTA	Camry	5	91>01	X			
TOYOTA	Carib		07>	X			
TOYOTA	Corolla Verso	5	00>04	X			
TOYOTA	Corolla Verso	5	04>07	X			
TOYOTA	Corolla Estate	5	02>05	X			
TOYOTA	Estima		00>05	X			
TOYOTA	Fortuner	5	05>		X		
TOYOTA	Highlander (XU20)		00>08		X		
TOYOTA	Highlander (XU20)		07>14		X		
TOYOTA	HiAce Regius		97>02		X		
TOYOTA	Hilux Sport Rider		98>04		X		
TOYOTA	Hilux SW4		06>15	X			
TOYOTA	Ipsum		01>03	X			
TOYOTA	Kluger Grande		00>13		X		
TOYOTA	Land Cruiser		02>09		X		
TOYOTA	Land Cruiser	5	09>		X		
TOYOTA	Previa	5	00>05	X			
TOYOTA	Picnic	5	95>01	X			
TOYOTA	Prado		02>09		X		
TOYOTA	Prado		09>		X		
TOYOTA	Rav 4		00>04	X			
TOYOTA	Rav 4 (XA30)		05>12	X			
TOYOTA	Revo I		98>02		X		
TOYOTA	Revo II		00>02		X		
TOYOTA	Revo III		03>05		X		
TOYOTA	Rush		06>		X		
TOYOTA	Sequoia		01>07		X		
TOYOTA	Sequoia		08>		X		
TOYOTA	Sprinter SW		98>	X			
TOYOTA	Verso	5	09>		X		
TOYOTA	Vitz (P1)	5	99>05	X			
TOYOTA	Vitz (P1) Verso		00>05	X			
TOYOTA	Yaris (P1)	5	99>05	X			

Whilst every effort is made to ensure information is correct, Western Towing will not be held responsible for errors. Always check your vehicle handbook for guidance before fitting a roof bar

MAKE	MODEL	N° OF DOORS	YEAR	For vehicles with factory fitted roof rails			
				EAGLE RB1040	XL EAGLE RB1045	M-PROFILE RB1030	M-PROFILE RB1035
TOYOTA	Yaris Verso		00>05	X			
VAUXHALL	Agila (A)	5	00>07		X		
VAUXHALL	Antara	5	06>		X		
VAUXHALL	Astra Sports Tourer (F)	5	91>97	X			
VAUXHALL	Astra Sports Tourer (G)	5	98>04	X			
VAUXHALL	Astra Sports Tourer (H)	5	04>11			X	
VAUXHALL	Astra Sports Tourer (J)	5	10>16			X	
VAUXHALL	Corsa Station Wagon		00>06	X			
VAUXHALL	Frontera		91>98		X		
VAUXHALL	Frontera		99>03		X		
VAUXHALL	Insigna Sports Tourer	5	09>13				X
VAUXHALL	Insigna Sports Tourer	5	13>				X
VAUXHALL	Mokka	5	12>			X	
VAUXHALL	Mokka X		16>			X	
VAUXHALL	Omega Break		86>04	X			
VAUXHALL	Sintra	5	96>99	X			
VAUXHALL	Vectra Estate	5	95>02	X			
VAUXHALL	Vectra Estate (C)	5	02>08			X	
VAUXHALL	Zafira	5	98>04	X			
VAUXHALL	Zafira (B)	5	05>08				X
VAUXHALL	Zafira (B)	5	08>12				X
VOLKSWAGEN	Bora Estate		99>05	X			
VOLKSWAGEN	Caddy Maxi		08>	X			
VOLKSWAGEN	Caddy Maxi Life		08>	X			
VOLKSWAGEN	Cross Up!		13>	X			
VOLKSWAGEN	Cross Fox		10>	X			
VOLKSWAGEN	Golf III (1H)		91>99	X			
VOLKSWAGEN	Golf IV (1J)	3	97>04	X			
VOLKSWAGEN	Golf IV (1J)	5	97>04	X			
VOLKSWAGEN	Golf V (1K) Plus	5	03>08	X			
VOLKSWAGEN	Golf VI (5K) Plus	5	08>12	X			
VOLKSWAGEN	Golf VII (5G) Plus		13>	X			
VOLKSWAGEN	Golf V (1K) Cross		06>10	X			
VOLKSWAGEN	Golf VI (5K) Cross		10>14	X			
VOLKSWAGEN	Golf V (1K) Estate		03>08	X			
VOLKSWAGEN	Golf III (IH) Estate	5	94>99	X			
VOLKSWAGEN	Golf IV (1J) Estate	5	97>04	X			
VOLKSWAGEN	Golf VI Estate	5	08>12	X			
VOLKSWAGEN	Golf VII (5G) Estate		13>	X			
VOLKSWAGEN	Golf VII (5G) Sport Van	5	14>	X			
VOLKSWAGEN	Jetta (A4) Estate		98>05	X			
VOLKSWAGEN	Jetta Estate		08>	X			
VOLKSWAGEN	Parati II		94>13		X		
VOLKSWAGEN	Passat (B5) Estate		96>05	X			
VOLKSWAGEN	Passat (B6) Estate		05>10	X			
VOLKSWAGEN	Passat (B7) Alltrack		12>14	X			
VOLKSWAGEN	Passat (B7) Estate		11>14	X			
VOLKSWAGEN	Passat (B8) Estate		14>				X

Whilst every effort is made to ensure information is correct, Western Towing will not be held responsible for errors. Always check your vehicle handbook for guidance before fitting a roof bar

MAKE	MODEL	N° OF DOORS	YEAR	For vehicles with factory fitted roof rails			
				EAGLE RB1040	XL EAGLE RB1045	M-PROFILE RB1030	M-PROFILE RB1035
VOLKSWAGEN	Pointer II		94>13		X		
VOLKSWAGEN	Polo III (6N) Estate		95>99	X			
VOLKSWAGEN	Polo III (6N2) Estate		99>03	X			
VOLKSWAGEN	Polo IV (9N3) Cross		06>08	X			
VOLKSWAGEN	Polo IV (9N3) Fun		03>08	X			
VOLKSWAGEN	Polo V (6R) Cross		10>	X			
VOLKSWAGEN	Sharan	5	95>09		X		
VOLKSWAGEN	Sharan	5	10>		X		
VOLKSWAGEN	Space Fox		06>	X			
VOLKSWAGEN	Sports Van		14>	X			
VOLKSWAGEN	Suran		06>14	X			
VOLKSWAGEN	Tiguan (5N)	5	07>11	X			
VOLKSWAGEN	Tiguan (5N)		11>16	X			
VOLKSWAGEN	Tiguan Cross	5	14>		X		
VOLKSWAGEN	Tiguan II	5	16>		X		
VOLKSWAGEN	Touareg (7L)		02>06	X			
VOLKSWAGEN	Touareg II (7P)	5	10>13		X		
VOLKSWAGEN	Touareg II (7P)	5	14>		X		
VOLKSWAGEN	Touran I (1T)	5	03>10		X		
VOLKSWAGEN	Touran I (1T)	5	10>15		X		
VOLKSWAGEN	Touran II (5T)		15>		X		
VOLVO	V40	5	95>12	X			X
VOLVO	V40 Cross Country	5	13>		X		
VOLVO	V50	5	04>08	X			
VOLVO	V50	5	08>12	X			
VOLVO	V70	5	00>07		X		
VOLVO	V70	5	07>13		X		
VOLVO	V70	5	13>		X		
VOLVO	V90		16>				X
VOLVO	XC60	5	08>13				X
VOLVO	XC70	5	08>13		X		
VOLVO	XC90	5	02>06		X		
VOLVO	XC90		14>				X
VOLVO	XC90	5	06>14		X		

Whilst every effort is made to ensure information is correct, Western Towing will not be held responsible for errors. Always check your vehicle handbook for guidance before fitting a roof bar